

# SUPPORT BRACKETS



## MAKE: IRONMAN

### Flat - 12" x 2 1/2" x 3/8"

- Flat brackets typically want a 2" x 4" type substrate to fasten to.



### Right Angle - 8" x 8" x 3/8"

- Angle brackets are more structural and preferred for support.
- Angle brackets will fasten to the vertical surface of the cabinets or knee wall.
- Spacing: Brackets should be spaced every 24". Some scenarios may require more or less depending on material, overhang size and shape of piece.
- Carried on all template trucks
- We do not install brackets but we will review placement with onsite contact.

